

## Spare Parts Kits

### Optional Fittings

Each stirred reactor is furnished with a set of spare parts and fittings consisting of a 6 foot gas supply hose, head gaskets, rupture discs, and a set of replacement parts for the stirrer drive.

A reserve supply of spare parts can be ordered from the list below to provide sufficient parts and tools to handle most normal replacements and emergency repairs during the first year of heavy usage. These kits include replacement gaskets, O- rings, drive belts and seals. These kits are a convenient package of the small perishable items required for normal maintenance of the reactor.

When ordering any kit for an existing reactor please specify the preferred gasket/seal material, the range of the rupture disc, material of the reactor and the length of the drive belt.

Spare Parts Kits for Reactors	
Part No.	Reactor Series
4509M	4521,22 w/mag drive in 1370HC Series Heads
4539M	4531,32 w/mag drive in 1370HC Series Heads
4539MA	4531/32 w/HD mag drive/755HC Head
4549MA	4544-47 Bench Top
4549MB	4544A-47A, 4544C-46C Floor Stand
4559M	4551,52 with magnetic drive
4569M	Series 4560 w/magnetic drive
4579B	Series 4570 HP/HT Reactor
4579D	Series 4575-76 HP/HT Reactor
4589B	Series 4580 HP/HT Reactor
4599	Series 4590 Mirco Reactor
4559PCM	Series 4555 Reactor
5109M	Series 5100 Glass Reactor
5119M	Series 5110 Glass Reactor